









Yleisimmät mallit.  
Normaalisti varastossa.  
Muut mallit tilauksesta.

## Keskiasennussarjat



	Koodi nro	Nimi	Sopivuus	Sopivuus	Sopivuus
	03-4000	Keskiasennussarja <b>super universal</b> Ø10 mm tapille	super universal for Ø10 mm tapille	Lähes kaikkiin malleihin	Varmista sopivuus
	03-11300	Keskiasennussarja <b>CF MOTO</b> Ø10 mm tapille	CFORCE 600 (2020+) CFORCE 600 Touring (2020+) CFORCE 625 CFORCE 625 Touring		
	75-373951	Keskiasennussarja <b>semi universal</b> Lukkokoukku 19mm	semi universal fØ19 mm lukkokoukku varten	KimpeX Click N & Go 2	Varmista sopivuus
	03-5000	Keskiasennussarja <b>Polaris</b> Ø10 mm tapille	Polaris Sportsman 450/570/ETX Ø10 mm tapille		
	03-3500	Keskiasennussarja <b>CanAm</b> G2 Ø10 mm tapille	Outlander 6x6 (2013-2016) Outlander 6x6 (2019+) Outlander 6x6 MAX (2017-2018) Outlander 6x6 MAX (2019+) Outlander G2 (-2016) Outlander G2 450/570 (2017+) Outlander G2 450/570 MAX (2017+) Outlander G2 650/850/1000 (2017-2018) Outlander G2 650/850/1000 (2019+)	Outlander G2 L MAX Outlander G2 MAX (-2016) Outlander X MR 1000 (-2016) Outlander X MR 1000 (2017-2018) Outlander G2 650/850/1000 MAX (2017-2018) Outlander G2 650/850/1000 MAX (2019+) Outlander G2 L	Outlander X MR 1000 (2019+) Outlander X MR 650/800/850 (-2016) Outlander X MR 650/850 (2017-2018) Outlander X MR 650/850 (2019+) Renegade G2 (-2016) Renegade G2 (2017-2018) Renegade G2 (2019+) Renegade X MR (-2016) Renegade X MR (2017-2018) Renegade X MR (2019+)
	03-5400	Keskiasennussarja <b>Polaris</b> Ø10 mm tapille	Polaris 570 Touring X2 6x6 Big Boss Ø10 mm tapille		



Yleisimmät mallit.  
Normaalisti varastossa.  
Muut mallit tilauksesta.

## Keskiasennussarjat



	Koodi nro	Nimi	Sopivuus	Sopivuus
	03-1700	Center mounting kit - Mounting bracket <b>Polaris</b> Ø10 mm pins	Scrambler 850/1000 (-2014) Scrambler 850/1000 (2015+) Sportsman 1000 (-2016) Sportsman 1000 (2017+) Sportsman 550 Sportsman 850 (-2014) Sportsman 850 (2015+)	Sportsman Touring 550 Sportsman Touring 850 (-2014) Sportsman Touring 850 (2015+) Sportsman Touring XP 1000 (-2017) Sportsman Touring XP 1000 (2018+)
	03-9400	Center mounting kit - Mounting bracket <b>Kymco</b> Ø10 mm pins	MXU 700 (-2019) MXU 700 (2020+)	
	03-8500	Center mounting kit - Mounting bracket <b>CF MOTO</b> Ø10 mm pins	CFORCE 1000 CFORCE 850	
	03-2400	Center mounting kit - Mounting bracket <b>TGB</b> Ø10 mm pins	425 Blade 550 Blade 600 Blade 600 LT Blade	
	03-5100	Center mounting kit - Mounting bracket <b>Polaris</b> Ø10 mm pins	Ranger 570 (-2014) Ranger 570 (2015+)	
	03-6600	Center mounting kit - Mounting bracket <b>CF Moto</b> Ø10 mm pins	CFORCE 450/520-L CFORCE 450/520-S CFORCE 550 CFORCE 600 Cobalt / Iron Cobalt / Iron MAX	